



## Dash 32HF-HS and Dash 32HF Replacement Parts List

**Dash 32HF-HS Part Number 42830132**

**Dash 32HF Part Number 42830032**

**NOTE:** Most of the parts below are for all of the part numbers above. For parts that are unique, the part number of the Dash 32HF-HS or Dash 32HF is noted. If you need help determining which part number to use, please contact Technical Support ([techserv@astronovainc.com](mailto:techserv@astronovainc.com)).

Description	Part Number
A / D Differential Board (16 channels each)	42812001
Controller Board	42666101
SBC Board	13590611
Power Supply, 24V	26318200
Power Monitor Board	42656001
Display with touch controller	42448600
Touch Controller Board	26913100
Display - protective cover	32756200
Fan Assembly with harness (Qty of 2)	26212400
Harness - Keyboard / Mouse	14381200
Switch	11679003
Power cord	10787020
Ethernet Cable	25245011
Stylus Pen	13960100
OSM-32HF Operations Manual	22834540
Data Capture Drive (Part Number 42830032 only)	31862710
Data Capture Drive (Part Number 42830132 only)	26801020
System Drive (Part Number 42830032 only)	31862607

System Drive (Part Number 42830132 only)	<b>26801230</b>
DVD/CD RW Drive (Part Number 42830032 only)	<b>26514500</b>
Extended Warranty (covers parts and labor for one year)	<b>EW-D32HF</b>

*Parts for legacy products are subject to availability.*

Contact AstroNova for price and delivery information.  
F.O.B. Point: West Warwick, Rhode Island, USA  
Terms: Net 30 Days