



Dash 8HF-HS and Dash 8HF Replacement Parts List

Dash 8HF-HS Part Number 42830200

Dash 8HF-HS Part Number 42830100

Dash 8HF Part Number 42830000

NOTE: Most of the parts below are for all of the part numbers above. For parts that are unique, the part number of the Dash 8HF-HS or Dash 8HF is noted. If you need help determining which part number to use, please contact Technical Support (techserv@astronovainc.com).

Description	Part Number
A / D Board (4 Channels each)	42667002
Controller Board	42666101
SBC Board (Part Number 42830100 and 42830000 only)	13590611
SBC Board (Part Number 42830200 only)	13590620
Power Supply, 24V	26318200
Power Monitor Board	42656001
Display with touch controller	42448600
Touch Controller Board	26913100
Display - protective cover	32756200
Fan Assembly with harness (Qty of 2)	26212400
Harness - Keyboard / Mouse	14381200
Switch	11679003
Power cord	10787020
Ethernet Cable	25245011
Stylus Pen	13960100
OSM-8HF Operations Manual	22834490
Data Capture Drive (Part Number 42830000 only)	31862710
Data Capture Drive (Part Number 42830200 and 42830100 only)	26801020

System Drive (Part Number 42830200 only)	26801420
System Drive (Part Number 42830100 only)	26801220
System Drive (Part Number 42830000 only)	31862605
DVD/CD RW Drive (Part Number 42830000 only)	26514500
Paper (20 packs Z-Fold - 280 sheets) (Requires optional printer, SCR-8)	41427100
SCR-8 optional printer for Dash 8HF, Dash 8HF-HS	42755000
Extended Warranty (covers parts and labor for one year)	EW-D8HF

Parts for legacy products are subject to availability.

Contact AstroNova for price and delivery information.

F.O.B. Point: West Warwick, Rhode Island, USA

Terms: Net 30 Days